


Hardware Overview



LEDs

Power Indicator

Lights up green: powered on

Blinks green: the call is ringing

Line Keys






Lights up green: during the conversation / actions to make a call

Blinks red: the call is ringing

Off: line is idle

Place a call


Three ways to make a call:

- Handset:** Pick up the handset; enter the number, then press the send soft key or .
- Speaker:** Press  or the line keys; enter the number, and then press the send soft key or .
- Headset:** Press ; enter the number, and then press the send soft key or .



Note: You can dial the number from Contacts or Call Log, using one of three ways mentioned above. You can also change the call mode during the call.

End a call

To end a call in three different modes:


- Handset:** hang up the handset or press the cancel soft key
- Speaker:** press , or press the cancel soft key
- Headset:** press the cancel soft key

Answer a call

- Handset:** pick up the handset
- Speaker:** press 
- Headset:** press 

Note: You can also reject the call by press the Reject soft key.

Redial

Press  to redial the last call that dialed



Hold

Press the Hold soft key during a call to hold the call




Press the Resume soft key to resume the call.

Call Transfer




Blind Transfer

- Press  or transfer soft key during the conversation, the call is on hold now.
- Enter the number that transfers to.
- Press  or transfer soft key, and now the blind transfer completed.

Attended Transfer (at least one line key set as Auto)





- Press  or transfer soft key during the conversation, the call is on hold now.
- Enter the number that transfer to, and press the send soft key or .
- Start the second conversation, press  or transfer soft key, then, transfer completed.

Semi-Attended Transfer (at least one line key set as Auto)

- Press  or transfer soft key during the conversation, the call is on hold now.
- Enter the number transfer to, and then press , then you can hear the ring tone.
- Press  or transfer soft key, and now the Semi-attended transfer completed.

Call Conference


Assuming that A and B are in conversation. A wants to bring C (or D & E) in a conference:

- A press line 2, the call is placed on hold.
- A enter the number of C and then press send soft key or . C answers the call.
- A press  or the conference soft key, then A, B and C are now in a conference.
- If add D&E, press Line 3, the current conference is on hold, dial D and press , the four are in conference. Press Line 4, and dial E, press , then A,B,C,D,E are in conference.


Note: 1) If C does not answer the call, A can back to continue the conversation with B; 2) Once A hangs up the call, the conference is ended, although if B or C drops the call, A&C or A&B conversation continues.

Call Mute

Press  to mute the microphone during the call

Press  again to un-mute the conversation.

Quick Install Guide



Configuration

1. Configuration via Phone

- Press Menu→Setting→Advanced Settings (Default password: admin)
- Network submenu: To configure the Wan Port, select connection type: DHCP/Static/PPPoE
- Accounts submenu: To configure the Account, set the Account state enable, fill the SIP Server, Outbound Proxy, User ID, etc (depends on your ISP's requirements)
- Save the configuration

2. Configuration via Web

- Get the WAN IP address: Press Menu→ Status. You can also use local IP address if your PC connected to the PC Port of the phone (192.168.1.1 as default)
- Web access: input the IP address in the web browser (If use WAN IP address, PC and phone should be in the same subnet). Login/password: admin/admin (default)
- Configuration: select Network/Account menu to fill the network and SIP account settings
- Save the configuration, or if want to reboot, click the reboot button.

Ordering Information

LV-3SC: 3x SIP Accounts; 2x FE Ports; Color Graphic LCD

LV-3SC-P: 3x SIP Accounts; 2x FE Ports; Color Graphic LCD; PoE Support

LV-3SCG-P: 3x SIP Accounts; 2x GE Ports; Color Graphic LCD; PoE Support

Support Contact

If you have any questions about LAVoice Series Enterprise IP Phones, please contact the support team: support@lavatele.com

To find all documentation, solutions, tutorials and other useful information, please visit our web: www.LAVATele.com



LV-3SC (G/-P)

LAVoice Series Enterprise IP Phone

Quick Installation Guide